CABINET PARTS

REFRIGERATOR

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	LIT2205958	Use & Care Guide
	LIT2204338	Service & Wiring Sheet
	LIT2206411	Energy Label
	LIT628370	Modular Icemaker Service Sheet
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
9	2156056	Shim
12	2196046	Hinge Top (2)
13	2196048	Shim, Hinge Top
14	489284	Screw
15		Hinge Cover
	1129262	White
	2186858	Biscuit
	2151694	Black
16	2171851	Hinge Bottom (2)
21		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
22		Grille
	2198470W	White
	2198470T	Biscuit
	2198470B	Black
23	489497	Screw
35	489464	Screw
41	940139	Drain Fitting
42	1108438	Extension Tube
43	1108439	Clip, Drain Tube
47	2176140	Cover, Unit
48		Cabinet (Not A Serviceable Part)
49		Hinge Cover
	1119787	White
	2186857	Biscuit
	2155938	Black
52	549193	Clamp, Service Cord
53	489084	Screw
54	2155311	Door Closer, Lower Cam (2)
55	489483	Screw

REFRIGERATOR LINER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	2182147	Louver
5	2171846	Release Valve
8	2196483	Stud Assembly (4)
9	8281158	Screw
11	489290	Screw (2)
13	2181796	Shelf Ladder
14	487539	Screw
15	2204329	Bracket, Water Filter
16	2204350	Cover, Water Filter
17	488163	Screw
18	2206039	Water Filter
19		Compression Nut
	2200083	Outlet
	2204357	Inlet
22	1123919	Bracket Retainer
23		Water Tube
	2205815	Outlet
	2205814	Inlet
24	2208271	Air Diffuser Assembly
25	2152019	Air Diffuser Cover
26	2150331	Cover, Conduit
27	486298	Screw
28	2204409	Air Diffuser, Cover
29	2162085	Socket
31	2196171	Reservoir
33	527949	Light Bulb
34	2203266	Light Lens
35	2205813	Strap
37	488280	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2194281	Shelf, Cantilever (2)
2	2174150	Glass, Cover
3	2194578	Cover, Crisper
4	2194905	Trim, Pan
5	2179259	Glass, Cover
6	2179350	Deflector
7	2194906	Trim, Meat Pan
8	2189601	Cover, Meat Pan
10	2196229	Crisper Pan
11	2196231	Meat Pan
12	2182730	Egg Bin
13	2179243	Trim, Snack Pan
15	2209601	Shelf, Snack Bin
18	2196233	Snack Bin
20	2196483	Stud Assembly
21	2196485	Stud Assembly
22	3400895	Screw
23	8281158	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	2209674	Bracket, Fill Tube
3	2171713	Door, Ice Compartment
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud (4)
10	2176134	Grommet
11	2182971	Freezer Bin
14	2155572	Wiring Cover
15	489355	Screw
17		Slide, Basket
	2181760	Right Side
	2181759	Left Side
18	486298	Screw
19	1115373	Switch, Rocker Arm
20	8281158	Screw
21	2196483	Stud Assembly
23	2171714	Shelf, Top Compartment
24	2171705	Light Lens
25	527949	Light Bulb
26	2162085	Light Socket
27	2196207	Stud, Rear
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
30	3400893	Screw
31	2174268	Shelf (2)
	2174267	Shelf (1)

MOTOR AND ICE CONTAINER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2183726	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Soleniod Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2186815	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196091	Ice Container
15	983668	Coupling, Conveyor
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2181955	Conveyor
28	2196194	Drum
29	3400912	Washer
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
41	2152021	Sleeve, Auger
44	2204321	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

REFRIGERATOR DOOR PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 6)
	2194509W	White
	2194509T	Biscuit
	2194509B	Black
2	2177105	Door, Compartment
3	489491	Screw
4	2187194	Shelf Bin (3)
5		Extension, Handle
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
6		Door Gasket, Magnetic (Repair)
	2159075	Mist Beige
	2159083	Black
7		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
8	2182180	Thimble−Top
9	2195327	Clip (4)
10		Extension, Handle
	2194973W	White
	2194973T	Biscuit
	2194973B	Black
11	2182178	Door Closer, Upper Cam
12	489420	Screw
13	2195950	Bracket, Door Stop
19	3400852	Screw
22	2177962	Trivet, Shelf
23	3400012	Screw

FREEZER DOOR PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	2205865W	White
	2205865T	Biscuit
	2205865B	Black
2		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
3	2182181	Thimble−Top
4	489491	Screw
5	2195327	Clip (4)
6	2194501	Trivet, Shelf (4)
7	3400012	Screw
8		Door Gasket, Magnetic (Repair)
	2159074	Mist Beige
	2159082	Black
9	2209681	Trim, Door Shelf
10	8281149	Screw
11	2183713	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14	2195950	Bracket, Door Stop
17		Extension, Handle
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
18		Extension, Handle
	2194973W	White
	2194973T	Biscuit
	2194973B	Black
22	3400852	Screw
23	2154473	Connector

DISPENSER FRONT PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	489101	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2180208	Door Mechanism Assembly
8	2180223	Mechanism Delay
9		Grille, Overflow
	2183787W	White
	2183787T	Biscuit
	2183787B	Black
10	2180225	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2195089W	White
	2195089T	Biscuit
	2195089B	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (2)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2195090W	White
	2195090T	Biscuit
	2195090B	Black
18	2180279	Switch Assembly (Also Order #19)
19		Overlay, Front Cover
	2205861W	White
	2205861T	Biscuit
	2205861B	Black
20	2196198	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2205863W	White
	2205863T	Biscuit
	2205863B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief

UNIT PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204242B	Condenser Assembly
4	489464	Screw
5	2208280	Clip, Wire
6	489099	Screw
7	934011	Clip, Tube (3)
8	2161302	Sleeve
9	2158826	Dampener
10	509812	Grommet
11	488687	Screw
12		Cover
	2162358	(Production Alternate)
	4387731	(Service)
13		Overload
	2187145	(Production Alternate)
	4387835	(Service, Includes Relay)
14	2205765	Tube Suction
15		Relay
	2188393	(Production Alternate)
16	2204413	Start Device, Combination (Production Alternate)
17	4387764	Capacitor (Service Compressor Only)
21	489478	Screw
22	2209611	Evaporator
23	2161324	Clamp
24	2176336	Fan, Motor
25	1110674	Tray, Evaporator
26	2149294	Heat Shield
27	2199167	Drier
28	2183455	Compressor (Includes Items 12, 13, 16, 17, 27) (Also Order 876765 Tube Kit)
30	2157396	Unit Mounting Frame
31	2188353	Unit, Harness (Includes Power Cord)
32	2181929	Fan, Motor Bracket
33	2188175	Heater, Defrost
34	2161330	Clip
35	2196155	Bi−Metal, Defrost
37	489387	Screw
39	2183042	Grommet (4)
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat Shield
43	2206281	Unit Cover, Bottom
44	489396	Clip
48	1127906	Unit Mounting Rail
49	488624	Screw
50	1110663	Guard, Fan
52	2172840	Strap
53	489427	Screw
54	227991	Wire Connector
55	488649	Screw
63	2196152	Union

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.75 oz.
(R−134A)

AIR FLOW PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
5	2203593	Air Duct Freezer
7	2149299	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	2182146	Duct, Icemaker
12	2186800	Harness, Fan Evaporator, And Heater, Bi−Metal
13	2155789	Gasket Cover
14	2172840	Wire Tie
16	2203876	Gasket
17	2203841	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2200137	Control Box
2	1110629	Mounting Bracket
3	3196537	Screw (4)
4	2149705	Light Switch
6	2176648	Defrost Timer (10 Hr.)
7	489398	Screw (2)
8	940014	Hole Plug
9	2198202	Thermostat
10	487869	Screw
11	2182195	Cam Assembly
12	1110560	Bearing Body
14	2196062	Clip, Damper Control
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	2196001	Thermostat, Barrier
19	527949	Light Bulb
20	2186802	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push−On
25	2194977	Escutcheon, Control Box
26	2182111	Thermostat, Knob
27	2197871	Knob, Air Control
29	489203	Spring Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2196157	Fitting, Water Tube
5	628379	Clip, Fuse
7	2181940	Tube, Water
9	489478	Screw
10	2206123	Valve, Solenoid
11	627018	Nut, Compression
14	489385	Tube Clamp
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	2171593	Shut Off Arm
32	628256	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Items 37 & 38)
36	488208	Screw
37	628398	Motor
38	489136	Screw
40	1129179	Nut, Compression
100	4317943	Complete Icemaker Assembly

PARTS NOT ILLUSTRATED

For Models: ED25PEXHW00, ED25PEXHT00, ED25PEXHB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up Kit (Black)

* **CAUTION:** The spray paint is not to be used where the paint may make contact with the door gaskets.

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

Illus. No.	Part No.	DESCRIPTION

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	2204349	Ice Container Assembly
	2149072	Ice Crusher Mechanism Assembly

TORX SCREW WRENCH

	1117510	Torx Key